



# APOLLO 924 REFERENCE GUIDE


## Controls








## Display Symbols









### Turning Your Pager On

Press , to turn the pager power on.






### Turning Your Pager Off

- \* Press , then, press  again to "PAGER OFF" mode.
- \* Press , till "PAGER OFF ?" appears on the screen.
- \* Press , to turn the pager off.
- \* After turning your pager off, the screen is empty.
- \* Press , to turn the pager power on.













### Setting The Time And Date

- \* Press , then, press  once until "SET TIME" Mode is displayed.
- \* Press , to enable set time.
- \* Press , to move the cursor to the hour / minute digit. Then, press ,
- \* to adjust each set of digits : AM/ PM/24 hr / month / day.
- \* Press , to activate the time and date change.





### Receiving And Reading Your Message

- \* A flashing  symbol indicates you have a message has not been read. (The symbol  of mail drop shows on screen by flashing).
- \* Press , once, to preview the message.
- \* Press , to display your message., Press , once, to view the next screen.
- ★ If you have set " Auto Scroll ", your pager will scroll through your message screen by screen automatically.






### Setting The Alert

- \* Press , then, press  once to display " SET ALERT " Mode .
- \* Press , to enable "SET ALERT".
- \* Press , to move the cursor to the desired alarm mode. ( Alert  / Musical  / Vibration  / Sleep  are optional )
- \* Press , to move to the cursor to the desired tone or music .
- \* Press , setting the alert is completed.
- \* The  symbol is displayed if the message receiver is in the audible mode .
- \* The  symbol won't display on screen if the receiver is in the silent mode or sleep mode.




### Reading Personal Message

- \* Press , to move the flashing icon to the  symbol.
- \* Press , to read message.
- \* When the  symbol is shown in the top left-hand corner of the display, indicates the message status as a personal message.







### Deleting Messages

- \* Press , to move the cursor to select the message you desire. Press , to read the message.
- \* Press , press  once, to display " MESSAGE DELETE " Mode.
- \* When " MESSAGE DELETE ? " is displayed on the screen, press , to delete the message.





### Deleting All Messages

- ( All unlocked and read messages )
- \* Press , press  again, to " DELETE ALL " Mode .
  - \* When " DELETE ALL ? " is displayed, Press , all unlocked and read messages are now deleted.




### Locking Messages

- \* Press , to move the cursor to the desired flashing symbol. .
- \* Press , press  once to select the desired message to lock.
- \* Press , to lock the message. .
- \* The symbol  is displayed, indicating the status of the message in memory.

### Unlocking Messages

- \* Press , to move the cursor to select the message to unlock.
- \* Press , then, press  once, to " MESSAGE UNLOCK " Mode.
- \* Press , to unlock the message.

### Battery Gauge

The battery indicator is located on the status screen and keeps you informed of battery energy level. The three indicators range from  (full),  (1/2),  (low). Whenever the low battery shows on display, Please replace the new battery in to make sure the pager is in receivable condition.